


Amana SLW330RAW (BOM: PSLW330RAW) 01 - Agitator, Drive Bell, Washtub and Hub



Amana Residential Amana SLW330RAW (BOM: PSLW330RAW) Washer Parts Parts Diagram 01 - Agitator, Drive Bell, Washtub and Hub

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	40063301	3400527		Screw
2	40002901	27001052		Balance Ring
3	40000802P	719P3		Assembly- Wash
4	40008001			Filter, Lint
5	40016101			Seal, Bell Drive
6	R9900457			Kit, Hub And Seal
7	40016301			Nut, Lock
8	40008301			Insert, Spline
9	R9900189			Kit, Drive Bell And Seal
10	40065102			Screw, Shoulder 1/4
11	40008401			Plug, Bell
12	40000501G	40000501W		Agitator, Flex Vane
13	40002101G	40002101W		Assembly, Fabric Softner