



Amana Residential Amana TEA400 (BOM: P7575203W) Dryer Parts Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603020		Not Available	CONTROL PANEL
2	R0600002		Not Available	SCREW
3	R0603005		Not Available	END, CONTROL HOOD
4	R0603004		Not Available	HOOD END RH
5	R0604004		Not Available	TIMER
6	R0601001		Not Available	NUT
7	R0603528		Not Available	TIMER KNOB ASSY
8	R0603501		Not Available	SWITCH BUTTON
9	R0603527		Not Available	SWITCH BUTTON
10	R0600003	70212		Screw, 8-32 X 5/32 RD H
11	R0601501		Not Available	CLIP
12	R0601004	24522		Nut, Speed-8ab-18 C1995
13	R0600001	W10116760		Screw
14	R0603007		Not Available	CONTROL KNOB ASSY
15	R0605503		Not Available	SLEEVE
16	R0605549		Not Available	PANEL SUPPORT

17	R0603021	Not Available	CONTROL HOOD-WHITE
"	R0603056	Not Available	CONTROL HOOD ALMOND
19	R0602514	Not Available	SELECTOR SWITCH

