



Amana Residential Amana TW3303G (BOM: P1128408W G) Washer Parts Parts Diagram 07 - ROTARY TIMER CONTROL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33102		Not Available	ASSY,HOOD & MTG PLATE-
2	31248			Cap, End-RH-Chrome
"	31249		Not Available	CAP,END-L.H.-CHROME
3	33963		Not Available	PANEL,GRAPHIC-AMANA
4	32039			Timer, 4 Cycle
5	32997		Not Available	ASSY,TIMER SKIRT&RING-
6	32622		Not Available	TIMER KNOB
7	31260			Screw, No.8 X 3/8 Ind H
8	31266			Switch, Pressure-Rotary
9	21300		Not Available	SWITCH,TEMPERATURE
"	28118		Not Available	SWITCH,WATER TEMPERATU
10	57584		Not Available	NUT
NI	23962	W10116760		Screw
12	32866			Assembly, Knob-Rotary-Black
13	10519		Not Available	RETAINER

14	33619	Not Available	CONTROL HOOD REAR PANEL
15	23962	W10116760	Screw
16	31752	Not Available	SCREW, No.8ABX3/4 POZIDRI
18	32874	Not Available	TRIM,BOTTOM-AMANA

