


Amana UE8031 05 - CONTROL PANEL & CONTROLS (WASHER)



**CONTROL PANEL AND CONTROLS
(Washer Components)**

Amana [Residential Amana UE8031 Washer Parts](#) Parts Diagram 05 - CONTROL PANEL & CONTROLS (WASHER)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	23962	W10116760		Screw
2	30125		Not Available	TIMER,3 CYCLE-60HZ 115
3	29808		Not Available	PLATE,SWITCH MOUNT
4	Y00000000		Not Available	SEE NOTE GROUND WIRE, GREEN
5	30150			Switch, Pressure-Variab
6	29880		Not Available	TUBING,PLASTIC-11 INCH
7	30138	Y304244		Motor Pulley With Set Screw
8	Y00000000		Not Available	SEE NOTE PRESSURE HOSE
9	29869		Not Available	TUBING,PLASTIC-3 INCH
10	30149			Switch, Pressure-Single
11	29910		Not Available	BUTTON,CONTROL-DARK BR
12	30107			Switch, 5 Position
13	30039		Not Available	COVER, SWITCH
14	28778			Button, Control-Beige

15	29857		Not Available	CAP,END-R.H.
16	29855		Not Available	GASKET,SHIELD
17	Y00000000		Not Available	SEE NOTE WASHER OUTER CABINET
18	29896		Not Available	PHILLIPS HEAD SCREW
19	29890		Not Available	COLLAR
20	30292		Not Available	GASKET,END CAP & ADHES
21	52864	500226		Screw, 8b-16 x 5/8 Tap
22	30302	3030-2		30 x 30 x 2 Cladlite AC Pad
23	30148		Not Available	HOSE,PUMP TO DRAIN
24	Y54608	31001575		Bulb, Cylinder Light
25	29809		Not Available	BRACKET,LIGHT
26	22145		Not Available	SCREW,6Z-20X 3/8 SS RD
27	30170		Not Available	ASSY,CONTROL PANEL-COM
28	28124		Not Available	ASSY,KNOB-SWITCH
29	10519		Not Available	RETAINER
30	29858		Not Available	NO LONGER AVAILABLE
31	29856		Not Available	GASKET,END CAP & ADHES
32	28287		Not Available	TIMER KNOB INDICATOR
33	29912			Assembly, Knob-Timer
34	26318			Screw, 8-32 X 1/4 Set S
35	26319			Spring

