


# Amana VA4013 13 - SWITCH AND BRACKET ASSY



Amana Residential Amana VA4013 Washer Parts Diagram 13 - SWITCH AND BRACKET ASSY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	29042		Not Available	SHIELD,LID SWITCH
2	Q6516		Not Available	SCREW,6-32 X 1 ROUND H
3	27249		Not Available	SWITCH
4	32394		Not Available	LEVER,OUT-OF-BAL SWITC
5	<a href="#">29043</a>			Nut, Push
6	<a href="#">27603</a>			Spring, Switch Lever
7	<a href="#">Y27837</a>			Clip, Speed-"U" Type
8	27248		Not Available	NUT,SPEED U-TYPE
9	27250		Not Available	BRACKET,OUT-OF-BAL SWI
10	<a href="#">27610</a>			Clip, U
11	Y00000000		Not Available	SEE NOTE CABINET TOP -- (SEE PAGE 2, KEY 18)
12	<a href="#">28193</a>			Screw, 8-1/2 Tapping W/