


Crosley CAH4205AWJ 06 - SPINNER ASSY & OUTER TUB COVER



Crosley [Residential Crosley CAH4205AWJ Washer Parts](#) Parts Diagram 06 - SPINNER ASSY & OUTER TUB COVER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	12002022			Lip Seal Kit
2	22003073	596669		Clamp, Manifold
3	22002123			Tube, Molykote
"	22004108			O Ring
"	22004081	W10181639		Support
4	22002023			Washer, Plastic
5	22002115	6-2717080		Spinner As
6	22002482			Washer, Profile
7	22002020			Washer, Spinner Support
8	22002122	2207454		Nut, Hex
9	22001985			Baffle, Drip
10	22002009			Grommet, Baffle
11	22001999			Grommet, Baffle
12	22002325	22003556		Screw, Baffle
13	22001986			Baffle, Drip
14	22002059			Screw, Baffle

15	22002077		Seal, Tub Cover
16	22002050		Clip, Tub To Cover
17	22004254		Cover, Tub W/Sealandcaps Aspk
18	12001772	12002533	Boot Kit
19	22002099		Spring, Tub
20	22002327		Wire, Boot Clamp
21	22003074		Guard, Hose
22	22003072		CLAMP, HOSE DOUBLE WIRE
23	22003071	22004477	Drain Hose, Door Boot

