


Crosley CAH4205AWW 01 - BASE WITH MOTOR



Crosley [Residential Crosley CAH4205AWW Washer Parts](#) Parts Diagram 01 - BASE WITH MOTOR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001988			Strut Assembly-Rear
2	Y052740	62739		Nut, Lock
3	22001915	22003544		Adjustable Leg W/Foot And Nut
4	22002244			Clip, Grounding
5	22003262			Hose, Tub To Pump Outlet
6	12001807			Drain Hose Kit
7	202515	596669		Clamp, Manifold
8	25001052			Pump Assembly
9	22003268			Cap, Rubber
10	22004500			Switch, Pressure-2 Level
"	22003265		Not Available	BAG, PLASTIC W/DRAWSTRING
"	22003728			Switch, Pressure Items 22-30 Listed As Series
"	22003728			Switch, Pressure Items 22-30 Listed As Series
"	22004500			Switch, Pressure-2 Level

11	22002853	285655	Clamp, Hose
12	22003605		Base Weld Assembly
13	22003298		Retainer, Wire
14	210684		Foot, Adjustable Leg
15	22001995		Screw Note: Screw, Tumbler Front And Shroud
16	22002239		Clip, Front Panel
17	22004473		Motor Control Assembly
"	22004473		Motor Control Assembly
"	22001995		Screw Note: Screw, Tumbler Front And Shroud
"	22004046		Control Assembly, Motor
"	22004046		Control Assembly, Motor
18	22003856		Motor, Variable Speed
19	22004212		Motor Harness
20	33002190		SCrew, C BraCe, BraCket, Cabinet
21	22004102		P Clips
22	22002019		Screw, Wire Clip To Motor Cnt
23	22003686		Bolt, Motor
24	22002320		Washer, Belt Tension Bolt
25	22003329		Isolator, Motor

