


# Crosley CAW9444XQ2 02 - CONTROLS AND WATER INLET PARTS

## CONTROLS AND WATER INLET PARTS

For Model: CAW9444XQ2  
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10467472

3

Crosley [Residential Crosley CAW9444XQ2 Washer Parts](#) Parts Diagram 02 - CONTROLS AND WATER INLET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10317196</a>			Panel, Console
2	<a href="#">8536939</a>			Clip, Knob
3	<a href="#">8559502</a>			Cap, End
4	<a href="#">8559501</a>			Cap, End
5	<a href="#">8312709</a>			Clip-Console
6	<a href="#">W10445399</a>			Control Unit Assembly, Machine And Motor
7	<a href="#">W10420985</a>			Panel, Console Rear Cover
8	1157158	<a href="#">489069</a>		Xxscrew, 10-12 X 1/2
9	<a href="#">W10268911</a>			Hose, Pressure Switch
10	<a href="#">90767</a>			Screw, 8A X 3/8 HeX Washer Head Tapping
11	<a href="#">W10276649</a>			Cord, Power
12	<a href="#">3400076</a>			Screw, Bracket Mounting
13	<a href="#">W10317457</a>			Knob, Timer Assembly
14	<a href="#">W10317458</a>			Knob, Control
15	<a href="#">W10285512</a>			Switch, Rotary Encoder

16	<a href="#">W10291174</a>		Harness, Upper
17	<a href="#">W10432353</a>		Inlet Assembly, Water
18	<a href="#">W10356257</a>		Valve, Water Mixing
19	<a href="#">W10441423</a>		Vacuum Break
20	<a href="#">W10238347</a>		Hose, Vacuum Break
21	W10117298	<a href="#">596669</a>	Clamp, Manifold
22	<a href="#">W10344775</a>		Harness, Valve
23	<a href="#">8281163</a>		Screw, Dispenser Housing Mounting
24	<a href="#">W10272474</a>		Pushbutton, Start
25	<a href="#">W10348582</a>		Cable Tie

