


Crosley CDE20C5 04 - HEATER (ORIG. REV. A-C)

MASTER CARE

CDE20C5

HEATER



Issued 11/85

N-27-28

Crosley [Residential Crosley CDE20C5 Dryer Parts](#) Parts Diagram 04 - HEATER (ORIG. REV. A-C)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	53-0500	LA-1044		Element
"	25-7863			Screw
2	53-0191			Heater Housing Assembly
"	25-7819	M0217225		Screw
3	53-0306	53-0771		Thermostat, Hi-Limit
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
4	53-0285			Bracket, Thermostat
"	25-7741	W10116760		Screw
5	53-0166	53-1518		Block, Terminal
"	25-7803	3400074		Screw
"	25-6124		Not Available	NUT
"	25-3123		Not Available	WASHER, CUP
"	25-3122			Washer, Flat
"	25-0027	112432		Nut