


Crosley CDE20R7A 03 - MOTOR & DRIVE (REV. A-B)



Crosley [Residential Crosley CDE20R7A Dryer Parts](#) Parts Diagram 03 - MOTOR & DRIVE (REV. A-B)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	63-5519		Not Available	LEG, LEVELING
2	53-0120			Clip, Front Panel
3	25-7027	16515		Clip
4	53-0153		Not Available	SHIELD, WIRING
"	25-7741	W10116760		Screw
5	53-2275	W10410996		Motor-Drive
"	53-1041	LA-1004		Motor Mtg. Kit
6	53-0693	53-0332		Motor Switch
7	25-7811		Not Available	SCREW
"	53-1932	31001570		Bracket, Motor
"	53-0852		Not Available	MOTOR BRACKET
8	25-7674			Screw
"	53-0214	660658		Clamp, Motor Mounting 343481 685441
9	53-2287			Idler Assembly
"	53-2250	53-2287		Idler Assembly
"	53-1628	31001344		Pulley, Idler

"	25-7815		Washer
"	25-7957		Pushnut
"	53-1650	Not Available	IDLER ASSY
10	53-2209	31001465	Spring, Idler
"	53-1648		Idler Spring
11	53-0134		Duct, Exhaust
"	25-2134	W10116760	Screw
12	53-1801		Housing, Blower
"	53-0774	Not Available	BLOWER HOUSING
13	53-1023		Blower Cover
"	53-0203	12001324	Duct Kit, Collector
14	53-0106		Blower Wheel
15	25-7823	312967	Clamp, Blower Housing
16	25-7855		Ring, Retaining
17	25-2134	W10116760	Screw
"	53-1934		Cover, Blower Housing
"	53-1023		Blower Cover
"	53-1026		Guide, Vane Inlet
"	25-7807	33002917	Screw, No.10-16
18	53-1107		Thermostat, Control
19	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE
"	25-2134	W10116760	Screw
20	53-0182	31001356	Pad, Glide
21	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE
"	53-0183	31001469	Glide, Tumbler
22	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE
23	LA-1008		Rr Roller Kit
"	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE
24	53-0198		Support Assembly
25	25-7813		Spacer
26	53-0642	31001096	Roller
27	25-7854		Ring, Retaining
28	25-7814		Washer

