


Crosley CDE20T6W 04 - HEATER



Crosley Residential Crosley CDE20T6W Dryer Parts Parts Diagram 04 - HEATER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7863			Screw
"	53-1641	LA-1044		Element
2	25-7819	M0217225		Screw
"	53-1232			Heater Housing Assembly
3	53-0771			Thermostat, Hi-Limit
"	25-3083	212951		Screw, No.6-32 X 1/4 Inch
4	25-7741	W10116760		Screw
"	53-0285			Bracket, Thermostat
5	53-0965		Not Available	STRAP, GROUND
"	53-1518			Block, Terminal
"	25-0027	112432		Nut
"	25-7803	3400074		Screw
"	25-6124		Not Available	NUT
"	25-3123		Not Available	WASHER, CUP
"	25-3122			Washer, Flat
6	53-1182			Fuse, Thermal

