


Crosley CDE20T7A 02 - HEATER



Crosley [Residential Crosley CDE20T7A Dryer Parts](#) Parts Diagram 02 - HEATER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7863			Screw
"	53-1641	LA-1044		Element
2	53-1232			Heater Housing Assembly
"	25-7819	M0217225		Screw
3	25-3083	212951		Screw, No.6-32 X 1/4 Inch
"	53-0771			Thermostat, Hi-Limit
4	25-7741	W10116760		Screw
"	53-0285			Bracket, Thermostat
5	53-0965		Not Available	STRAP, GROUND
"	25-0027	112432		Nut
"	25-6124		Not Available	NUT
"	25-3122			Washer, Flat
"	53-1518			Block, Terminal
"	25-7952	3400074		Screw
6	53-1182			Fuse, Thermal
7	53-1181			Bracket, Thermal Fuse