


Crosley CDE22B7M 01 - CABINET



Crosley [Residential Crosley CDE22B7M Dryer Parts](#) Parts Diagram 01 - CABINET
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-2435-24			Top, Cabinet
2	53-2559-24	31001715		Cabinet And Base Assembly
3	63-5712			Hinge, Cabinet Top
"	33-0930			Pad, Top Hinge
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	LA-1007	12002126		Reinforcement Brace/Glide Kit
"	LA-1008			Rr Roller Kit
5	25-3034			Clip, Wiring
6	33-2653			Bumper, Cabinet
7	53-0643			Pin, Locator
8	25-0224	3400029		Nut, Adapter Plate
"	53-0200			Sleeve, Locator Pin
9	25-7828	489483		Screw 10-32 X 1/2
"	53-0135		Not Available	SUPPORT, POWER CORD
10	25-7857	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

"	53-0284		Cover, Terminal
11	63-5519	Not Available	LEG, LEVELING
12	53-0120		Clip, Front Panel
13	25-7027	16515	Clip
14	25-7733	681414	Screw, 10AB X 1/2
"	53-1921		Shield, Wiring
15	25-3457		Screw, Sems
"	53-0133		Shield, Heat

