


# Crosley CDE6000Q 02 - CONTROL PANEL CDE/CDG6000Q



Crosley [Residential Crosley CDE6000Q Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL CDE/CDG6000Q  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">31001484</a>			Resistor Assembly
"	<a href="#">31001476</a>			Panel, Control
2	<a href="#">21001769</a>			Endcap, Panel
3	<a href="#">21001768</a>			Endcap, Panel
4	<a href="#">21001772</a>			Knob, Selector
5	31001348	<a href="#">31001449</a>		Switch, Selector
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
6	31001475	<a href="#">31001506</a>		Knob/Skirt, Timer
7	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001517</a>			Shield, Control
8	31001119	<a href="#">W10116760</a>		Screw
"	<a href="#">53-1810</a>			Timer
9	<a href="#">21001767</a>			Frame
10	<a href="#">21001527</a>			Shield, Rear
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer

