


Crosley CDE6000Q 03 - DOOR CDE/CDG6000Q



Crosley [Residential Crosley CDE6000Q Dryer Parts](#) Parts Diagram 03 - DOOR CDE/CDG6000Q
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001480			Panel, Front
2	53-0120			Clip, Front Panel
3	25-7220			Clip, Cabinet Top
4	53-0643			Pin, Locator
5	25-0224	3400029		Nut, Adapter Plate
6	12001324			Duct Kit, Collector
7	53-0204			Seal
8	LA-1005			Switch Kit
9	53-0918			Filter, Lint
10	53-0281	31001747		Seal Assembly
11	31001478			Panel, Outer Door
12	31001479			Panel, Inner Door
13	53-0119			Clip, Hinge
14	53-1490			Door Pad
15	53-1491			Door Pad
16	53-0648	31001529		Seal, Door

17	25-7889		Plug Button
18	415013-35		Screw
"	31001482		Handle, Door
19	53-1492		Hinge, Dryer Door
20	53-0121	Not Available	TWIN NUT
21	53-2364	LA-1003	Door Catch Kit
22	53-0187	LA-1003	Door Catch Kit
"	LA-1003		Door Catch Kit
23	53-0147	53-0148	Switch, Door
24	31001319		Clip, Switch
25	33-2653		Bumper, Cabinet
26	31001280	12001324	Duct Kit, Collector

Howes
the laundry company®

Howes
the laundry company®

Howes
the laundry company®