


Crosley CDE8630 01 - CONTROL PANEL

MASTER CARE

CDE8630

BACKGUARD



Issued 5/86

N-28-19

Crosley [Residential Crosley CDE8630 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	63-6568		Not Available	WRAPPER
2	63-6735		Not Available	CONTROL PANEL
3	25-7649	910187		Screw
4	33-6765			LH End Cap
5	25-7496	25-7760		Screw
"	33-6766			RH End Cap
6	33-7923		Not Available	KNOB ASM
"	25-6044			Set Screw
7	33-5805			Selector Knob
8	63-5847		Not Available	CONTRL SHIELD
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
9	63-6880		Not Available	TIMER MOTOR
"	25-0289		Not Available	SCREW
"	63-6585		Not Available	TIMER
10	63-5350		Not Available	HEAT SEL SWITCH
				Screw, 8A X 3/8 HeX Washer

"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
11	25-7461		Not Available	CLIP
12	63-5954		Not Available	SHIELD
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

