


Crosley CDE9500W 08 - WIRING INFORMATION

CIRCUIT	FUNCTION	60	120	180	240	300	
1	YL-GY MOTOR	[Wiring grid]					
1A	GY-OR TIMER MOTOR	[Wiring grid]					
2	YL-PU MOTOR	[Wiring grid]					
3	PK-BU HEAT	[Wiring grid]					
4	PK-BK HEAT & SIGNAL PK-RO SIGNAL	[Wiring grid]					
CONTACTS OPEN		REGULAR FABRICS	TIMED DRY	PERMANENT PRESS	PRESS CARE		
CONTACTS CLOSED							



NOTE: Power cord provided on select models only.

2201016 A

*TEMP SWITCH DETAILS	
REGULAR	BU - RD
MEDIUM	BU - RD, PU - WH w/hi limit
DELICATE	BU - RD, PU - WH
DELICATE	BU - OR

(Heater may be internal or external to the switch.)

CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

Crosley [Residential Crosley CDE9500W Dryer Parts](#) Parts Diagram 08 - WIRING INFORMATION
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	15003425		Not Available	WIRING INFORMATION

