

Crosley CDG20P6A 04 - GAS CARRYING (ORIG. REV. A-D)



Crosley [Residential Crosley CDG20P6A Dryer Parts](#) Parts Diagram 04 - GAS CARRYING (ORIG. REV. A-D)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-0194	306176		Valve, Gas
2	63-3570			Burner Orifice
3	63-6615	279834		Coil-Valve
4	63-6682	31001784		Burner
5	25-7741	W10116760		Screw
"	53-0140			Mtg Bracket
6	53-0689	31001556		Igniter
7	25-7744	8281196		Screw
"	53-0686		Not Available	BRACKET
"	25-3034			Clip, Wiring
"	25-2134	W10116760		Screw
8	53-0101	31001042		Valve, Gas Shut Off
9	53-0173	31001777		Main Gas L
10	53-1884			Housing, Heater
"	25-3032		Not Available	WIRING CLIP
"	53-0138		Not Available	HEATER HOUSING

11	25-7741	W10116760	Screw
"	53-0139		Not Available HEATER SUPPORT
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
12	25-0168		Screw
"	53-0143	LA-1053	Fuse Kit, Thermal
13	63-5013	338906	Radiant, Sensor
"	25-2134	W10116760	Screw
14	63-6259	31001547	Cord, Power
15	53-0169		Not Available INLET AIR DUCT
16	LA-1053		Fuse Kit, Thermal
"	53-1096	LA-1053	Fuse Kit, Thermal
"	63-6766		Conversion Kit

the laundry company[®]

the laundry company[®]

the laundry company[®]