


Crosley CDG20R7A 04 - TUMBLER



Crosley Residential Crosley CDG20R7A Dryer Parts Parts Diagram 04 - TUMBLER

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7733	681414		Screw, 10AB X 1/2
"	53-1708	LA-1054		Dryer Bulkhead Kit
2	53-0282	31001637		Seal Assembly, Cylinder Front
3	53-1250			Cylinder
4	25-7759	3196164		Screw
"	53-0117		Not Available	BAFFLE, GRAY
5	53-1512		Not Available	BELT, DRIVE
6	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
7	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
8	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
9	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
"	LA-1006			Glide Kit, Tumbler
10	25-7101	3351614		Screw, Gearcase Cover Mounting

"	53-0197		Support Assembly-Cylinder Rear
11	53-0642	31001096	Roller
12	25-7813		Spacer
13	25-7814		Washer
14	LA-1008		Rr Roller Kit
"	25-7854		Ring, Retaining

