


# Crosley CDG20R7W 06 - TUMBLER



Crosley [Residential Crosley CDG20R7W Dryer Parts](#) Parts Diagram 06 - TUMBLER  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	25-7733	<a href="#">681414</a>		Screw, 10AB X 1/2
"	53-1708	<a href="#">LA-1054</a>		Dryer Bulkhead Kit
2	53-0282	<a href="#">31001637</a>		Seal Assembly, Cylinder Front
3	<a href="#">53-1250</a>			Cylinder
4	25-7759	<a href="#">3196164</a>		Screw
"	53-0117		Not Available	BAFFLE, GRAY
5	53-1512		Not Available	BELT, DRIVE
6	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
7	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
8	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
9	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
"	<a href="#">LA-1006</a>			Glide Kit, Tumbler
10	25-7101	<a href="#">3351614</a>		Screw, Gearcase Cover Mounting

"	<a href="#">53-0197</a>		Support Assembly-Cylinder Rear
11	53-0642	<a href="#">31001096</a>	Roller
12	<a href="#">25-7813</a>		Spacer
13	<a href="#">25-7814</a>		Washer
14	<a href="#">LA-1008</a>		Rr Roller Kit
"	<a href="#">25-7854</a>		Ring, Retaining

