

Crosley CDG20T7A 02 - GAS CARRYING



Crosley [Residential Crosley CDG20T7A Dryer Parts](#) Parts Diagram 02 - GAS CARRYING
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	63-2098		Not Available	TAIL PIECE
"	63-6786N	306176		Valve, Gas
"	60-6846			Union Nut
2	63-3570			Burner Orifice
3	63-6615	279834		Coil-Valve
"	63-6614	279834		Coil-Valve
4	63-6682	31001784		Burner
5	53-0140			Mtg Bracket
"	25-7741	W10116760		Screw
6	53-0689	31001556		Igniter
7	25-3034			Clip, Wiring
"	53-0686		Not Available	BRACKET
"	25-2134	W10116760		Screw
"	25-7744	8281196		Screw
8	53-0101	31001042		Valve, Gas Shut Off
9	25-7741	W10116760		Screw

"	53-0173	31001777	Main Gas L
"	53-2362	31001777	Main Gas L
10	25-3032	Not Available	WIRING CLIP
"	53-1884		Housing, Heater
11	25-7741	W10116760	Screw
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-2363		Support, Heater Housing
"	53-0139	Not Available	HEATER SUPPORT
12	25-0168		Screw
"	53-0143	LA-1053	Fuse Kit, Thermal
13	25-2134	W10116760	Screw
"	63-5013	338906	Radiant, Sensor
14	63-6259	31001547	Cord, Power
15	25-7819	M0217225	Screw
"	53-1706		Inlet Air Duct Assembly
"	25-7741	W10116760	Screw
16	25-0168		Screw
"	LA-1053		Fuse Kit, Thermal
"	53-1182		Fuse, Thermal
"	53-1096	LA-1053	Fuse Kit, Thermal
"	25-3032	Not Available	WIRING CLIP
NI	63-6766		Conversion Kit
"	12001031		Conversion Kit

