


# Crosley CDG22B6V 02 - CONTROL PANEL



Crosley [Residential Crosley CDG22B6V Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

| Item | Original Part Number    | Replaced By              | Status        | Part Description                        |
|------|-------------------------|--------------------------|---------------|---|
| 1    | 31001157                |                          | Not Available | PANEL, CONTROL (WHT)                    |
| 2    | 35-2669                 |                          | Not Available | CAP, END (LT)(WHT)                      |
| "    | 35-2668                 | <a href="#">21001453</a> |               | Cap- End                                |
| "    | 25-3092                 | <a href="#">90767</a>    |               | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 3    | <a href="#">25-7702</a> |                          |               | Speedclip, End Cap To Control Panel     |
| 4    | 25-3092                 | <a href="#">90767</a>    |               | Screw, 8A X 3/8 HeX Washer Head Tapping |
| "    | <a href="#">53-1639</a> |                          |               | Buzzer Assembly                         |
| 5    | 31001055                |                          | Not Available | TRIM, ENDCAP (LT WHT)                   |
| "    | 31001054                |                          | Not Available | TRIM, ENDCAP (RT WHT)                   |
| 6    | <a href="#">25-7760</a> |                          |               | Screw                                   |
| 7    | <a href="#">25-7851</a> |                          |               | Speedclip, End Cap To Top               |
| 8    | 25-7649                 | <a href="#">910187</a>   |               | Screw                                   |
| 9    | 31001146                | <a href="#">31001193</a> |               | Pad, Shield                             |
| "    | 31001128                |                          | Not Available | SHIELD, CONTROL                         |

|    |                         |                           |                    |
|----|-------------------------|---------------------------|--------------------|
| 10 | 35-2688                 | <a href="#">21001460</a>  | Shield, Rear       |
| 11 | <a href="#">53-1758</a> |                           | Timer              |
| 12 | 31001119                | <a href="#">W10116760</a> | Screw              |
| 13 | <a href="#">53-2575</a> |                           | Timer Knob         |
| NI | 31001179                | Not Available             | MANUAL, USE & CARE |

