


Crosley CDG22B8V 01 - CABINET



Crosley [Residential Crosley CDG22B8V Dryer Parts](#) Parts Diagram 01 - CABINET
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	53-2435		Not Available	TOP, CABINET
2	53-2147	31001714		Cabinet And Base Assembly
3	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	63-5712			Hinge, Cabinet Top
"	33-0930			Pad, Top Hinge
4	LA-1007	12002126		Reinforcement Brace/Glide Kit
"	LA-1008			Rr Roller Kit
5	25-3034			Clip, Wiring
6	33-2653			Bumper, Cabinet
7	53-0643			Pin, Locator
8	53-0200			Sleeve, Locator Pin
"	25-0224	3400029		Nut, Adapter Plate
9	25-7857	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	53-0136			Cover, Supply Cord
10	53-0284			Cover, Terminal

"	25-7857	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
11	63-5834	Not Available	LEG, LEVELING
12	53-0120		Clip, Front Panel
13	25-7027	16515	Clip
14	53-1921		Shield, Wiring
"	25-7733	681414	Screw, 10AB X 1/2
15	63-6259	31001547	Cord, Power

