


# Crosley CDG4205AWJ 02 - CABINET



Crosley [Residential Crosley CDG4205AWJ Dryer Parts](#) Parts Diagram 02 - CABINET  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22002049</a>			Clip Note: Clip, Front Panel
2	<a href="#">22002049</a>			Clip Note: Clip, Front Panel
3	<a href="#">33002891</a>			Pin, Locator
4	<a href="#">33003034</a>			Cabinet Assembly, Dry-Gray As Pack
5	<a href="#">22004095</a>			Hinge, Plastic
6	<a href="#">22001995</a>			Screw Note: Screw, Tumbler Front And Shroud
7	<a href="#">33002190</a>			SCrew, C BraCe, BraCket, Cabinet
8	33002794	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
9	<a href="#">Y310376</a>			Clip, Door Switch Harness
10	<a href="#">33001807</a>			Seal, Tumbler
11	<a href="#">33002544</a>			Door, Inner W/Seal
12	<a href="#">22004497</a>			Door, Outer Washer-Gray As Pack
13	<a href="#">22002038</a>			Clip, Door

14	<a href="#">22002063</a>		Screw No.8-18AB Wafer Head
15	<a href="#">33001761</a>		Strike, Door
16	<a href="#">33001793</a>		Bracket, Strike
17	<a href="#">22002039</a>		Clip, Door
18	22002062	<a href="#">98006631</a>	Screw
19	<a href="#">33001759</a>		Hinge, Door
20	<a href="#">22002012</a>		Screw, Hinge Note: Screw, Hinge Bracket
21	<a href="#">33001763</a>		Plug, Inner Door
22	<a href="#">22004496</a>		Front Panel, Washer-Gray As Pack
23	<a href="#">22003781</a>		Screw, Ground Strap
24	Y312209	<a href="#">W10001200</a>	Screw
25	<a href="#">311093</a>		Washer, Terminal Connection
26	311484	<a href="#">112432</a>	Nut
27	<a href="#">Y312184</a>		Strap, Grounding
28	<a href="#">33001244</a>		Block, Terminal
29	33001826	Not Available	BRACKET, TERMINAL BLOCK---NA
30	<a href="#">33001795</a>		Cover, Terminal Block
31	<a href="#">33001764</a>		Cover, Hinge Hole
32	<a href="#">33001787</a>		Screw, Hinge Note: Screw, Hinge Hole Cover
33	<a href="#">33001767</a>		Seal, Shroud
34	<a href="#">33002597</a>		Hook, Security
35	Y304578	<a href="#">LA-1003</a>	Door Catch Kit
36	<a href="#">33001778</a>		Shroud
37	33001508	<a href="#">W10169313</a>	Switch-Dor
38	<a href="#">33001760</a>		Bracket, Hinge
39	<a href="#">22001995</a>		Screw Note: Screw, Tumbler Front And Shroud
40	<a href="#">33001768</a>		Screw, Shroud Note: Screw, Shroud And Outlet Duct

