


Crosley CDG4205AWJ 05 - TUMBLER



Crosley [Residential Crosley CDG4205AWJ Dryer Parts](#) Parts Diagram 05 - TUMBLER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33001794	33001889		Tumbler
2	33001807			Seal, Tumbler
3	33003037			Tumbler Back And Seal
"	33002779			Tumbler Back And Seal As-Pack
4	33001443			Nut, Hex
5	312535			Washer, Vault Mounting Brk.
6	Y312948	6-3129480		Shaft- Tumbler
7	12001541			Drum Roller/Washer Assembly--W
8	312535			Washer, Vault Mounting Brk.
9	410233	9703438		Ring-Retrn
10	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
11	33001808			Filter, Lint
12	33001799			Outlet Duct Assembly Note: Outlet Duct Assembly
13	33002560			Seal, Blower

14	Y303711		Sensor Ground Wire
15	210720		Rivet, Bearing To Tumbler Fmt
16	306508		Tumbler Bearing Kit ---W
17	312311	312311MAY	Screw
18	33001807		Seal, Tumbler
19	33001868		Front, Tumbler Front W/Sensor Note: Front, Tumbler
20	33001855	33002917	Screw, No.10-16
21	33001871		Screw Note: Screw, Drum Light
22	33001788	33002973	Screw, No.9-15 X 1.00 Hx WS
23	33002032		Baffle
24	312940	306508	Tumbler Bearing Kit ---W
25	33001755		Baffle

the laundry company[®]

the laundry company[®]

the laundry company[®]