


# Crosley CDG6000A 01 - CABINET



Crosley [Residential Crosley CDG6000A Dryer Parts](#) Parts Diagram 01 - CABINET  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001424		Not Available	TOP, CABINET (ALM)
2	53-2559-24	<a href="#">31001715</a>		Cabinet And Base Assembly
3	<a href="#">35-4128</a>			Pad, Hinge
"	<a href="#">63-5712</a>			Hinge, Cabinet Top
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	LA-1007	<a href="#">12002126</a>		Reinforcement Brace/Glide Kit
"	<a href="#">LA-1008</a>			Rr Roller Kit
5	<a href="#">25-3034</a>			Clip, Wiring
6	<a href="#">33-2653</a>			Bumper, Cabinet
7	<a href="#">53-0643</a>			Pin, Locator
8	25-0224	<a href="#">3400029</a>		Nut, Adapter Plate
"	<a href="#">53-0200</a>			Sleeve, Locator Pin
10	<a href="#">53-0284</a>			Cover, Terminal
"	25-7857	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
11	63-5519		Not Available	LEG, LEVELING

12	<a href="#">53-0120</a>		Clip, Front Panel
13	25-7027	<a href="#">16515</a>	Clip
14	<a href="#">53-1921</a>		Shield, Wiring
"	25-7741	<a href="#">W10116760</a>	Screw
16	63-6259	<a href="#">31001547</a>	Cord, Power

