


Crosley CED147HXW0 03 - BULKHEAD PARTS



Crosley [Residential Crosley CED147HXW0 Dryer Parts](#) Parts Diagram 03 - BULKHEAD PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	348368			Lint Chute Assembly
2	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
3	3388703			Washer, Support
4	347139			Seal, Lint Chute
5	3348629	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	696302			Shield, Exhaust
7	3392519			Thermal Limiter
8	8318268			Thermostat, Internal-Bias
9	3977393	279816		Cutoff-Tml
10	694089			Wheel, Blower
11	8577230			Housing, Blower
12	3398161			CLIP
13	343641	681414		Screw, 10AB X 1/2
14	8541818			Box, Heater
15	3977767			Thermostat, High Limit 250 F

16	3977373		Bracket, Drum Light
17	3403585	279838	Element
18	8066086		Plug, Drum Hole
19	279457		Wire Kit, Terminal
20	489463		Screw, 8-18 X 1/16
21	339956		Seal, Air Duct To Bulkhead
22	3403636		Baffle, Drum
23	90296		Nut, Push On
24	3390647	488729	Screw
25	3976479	279366	Electrode
26	3406124	22002263	Lamp
27	3402841	8532165	Lens, Drum Light
28	690997		Washer, Thrust
29	W10359270		Shaft, Drum Roller Threads
30	W10359269		Shaft, Drum Roller Threads
31	3397590	349241T	Support
32	348197		Washer, Support
33	W10298789		Nut, Push-In
34	3403414		Bulkhead
35	W10136369		Socket, Drum Light Assembly
36	692526	279441	BeaRng-Rng
37	W10219342		Screw, Baffle Mounting
38	W10352407	279857	Seal
39	695587		Drum Assembly
40	692490		Baffle, Drum
41	3976434		Bracket, Support Shaft
42	3393008	308685	Side Trim)

the laundry company[®]

the laundry company[®]