


Crosley CGD137SXQ0 03 - BULKHEAD PARTS



Crosley [Residential Crosley CGD137SXQ0 Dryer Parts](#) Parts Diagram 03 - BULKHEAD PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	348368			Lint Chute Assembly
2	489463			Screw, 8-18 X 1/16
3	3388703			Washer, Support
4	347139			Seal, Lint Chute
5	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
6	696302			Shield, Exhaust
7	3392519			Thermal Limiter
8	8066086			Plug, Drum Hole
9	3387134			Thermostat, Internal-Bias
10	694089			Wheel, Blower
11	8577230			Housing, Blower
12	3398161			CLIP
13	3390631			Screw, 10-16 X 3/8
14	8530285	279980		Box
15	3403140			Thermostat, High-Limit 205F
16	280010			Kit, Thermal Cut-Off

17	3390647	488729	Screw
18	8066049		Funnel, Burner Light
19	W10136369		Socket, Drum Light Assembly
20	3406124	22002263	Lamp
21	3977373		Bracket, Drum Light
22	3406022		Bracket, Bulkhead
23	339956		Seal, Air Duct To Bulkhead
24	690997		Washer, Thrust
25	3399506	W10359270	Shaft, Drum Roller Threads
26	3399507	W10359269	Shaft, Drum Roller Threads
27	3397590	349241T	Support
28	348197		Washer, Support
29	W10298789		Nut, Push-In
30	3403413		Bulkhead
31	338906		Radiant, Sensor
32	3402841	8532165	Lens, Drum Light
33	692526	279441	BeaRng-Rng
34	W10219342		Screw, Baffle Mounting
35	3406130	279857	Seal
36	695587		Drum Assembly
37	W10306677	692490	Baffle, Drum
38	3976434		Bracket, Support Shaft
39	90296		Nut, Push On
40	3403636		Baffle, Drum

the laundry company[®]

the laundry company[®]