


Crosley CGD147HXW0 03 - BULKHEAD PARTS



Crosley [Residential Crosley CGD147HXW0 Dryer Parts](#) Parts Diagram 03 - BULKHEAD PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	348368			Lint Chute Assembly
2	489463			Screw, 8-18 X 1/16
3	3388703			Washer, Support
4	347139			Seal, Lint Chute
5	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
6	90296			Nut, Push On
7	3392519			Thermal Limiter
8	8066086			Plug, Drum Hole
9	8318268			Thermostat, Internal-Bias
10	694089			Wheel, Blower
11	8577230			Housing, Blower
12	3398161			CLIP
13	343641	681414		Screw, 10AB X 1/2
14	8530285	279980		Box
15	3403140			Thermostat, High-Limit 205F
16	696302			Shield, Exhaust

17	339956		Seal, Air Duct To Bulkhead
18	8066049		Funnel, Burner Light
19	W10136369		Socket, Drum Light Assembly
20	3406124	22002263	Lamp
21	3403636		Baffle, Drum
22	3977373		Bracket, Drum Light
23	3406022		Bracket, Bulkhead
24	3390647	488729	Screw
25	280010		Kit, Thermal Cut-Off
26	3401707		Jumper, Tco-High Limit
27	3976479	279366	Electrode
28	690997		Washer, Thrust
29	W10359270		Shaft, Drum Roller Threads
30	W10359269		Shaft, Drum Roller Threads
31	3397590	349241T	Support
32	348197		Washer, Support
33	W10298789		Nut, Push-In
34	3403414		Bulkhead
35	338906		Radiant, Sensor
36	3402841	8532165	Lens, Drum Light
37	692526	279441	BeaRng-Rng
38	W10219342		Screw, Baffle Mounting
39	W10352407	279857	Seal
40	695587		Drum Assembly
41	692490		Baffle, Drum
42	3976434		Bracket, Support Shaft

the laundry company[®]

the laundry company[®]