


Crosley CSWS16445WQ0 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Model: CSWS16445WQ0
(White)

AUTOMATIC
WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

7-09 Litho in U.S.A. (drd)(bay)

1

Part No. W10285193 Rev. A

Crosley [Residential Crosley CSWS16445WQ0 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10200890		Not Available	INSTRUCTIONS, INSTALLATION (ENGLISH/FRENCH)
"	W10200891		Not Available	INSTRUCTIONS, INSTALLATION (SPANISH)
"	W10200883		Not Available	Use & Care Guide
"	W10200881		Not Available	Feature Sheet
"	W10062911		Not Available	ENERGY GUIDE
"	W10175555		Not Available	Wiring Diagram
2	W10194570			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	W10171313	W10193861		Lid
8	3351614			Screw, Gearcase Cover Mounting

9	W10192089	Dispenser, Bleach
10	9724509	Bumper, Lid
11	8318084	Switch, Lid
12	3390631	Screw, 10-16 X 3/8
13	W10119828	Screw, Lid Hinge Mounting
14	8319539	Bearing, Lid Hinge
15	W10225136	Hinge 7 Pad Assembly
16	91770	Hinge, Lid

