



**NON – ILLUSTRATED
PARTS**

the laundry company[®]

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts



Crosley [Residential Crosley CSWS16445WQ0 Washer Parts](#) Parts Diagram 09 - OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
NI	72017			Paint, Touch-Up
"	350938			Paint, Pressurized Spray B
"	350930			Paint, Pressurized Spray B
"	799344			Paint, Touch-Up)
"	350572			Oil
"	285208			Lubricant
"	285195			Sealer Sealer, Gasket
"	367031			Water System Parts
"	280129	280129A		Break-Sphn
"	280130	280130A		Adapter
"	280131	40922		Hose
"	8212546RP			Inlet Hoses, 4 Ft.
"	8212641RP			Inlet Hoses, 5 Ft.
"	8212545RP			Inlet Hoses, 5 Ft. (Two Black Hoses And One Blue Hose End And One 4 Rubber Washers) 4 Rubber Washers) (Two Braided Hoses (Tw

"	8212487RP	Inlet Hoses, 5 Ft.
"	8212637RP	Inlet Hoses, 6 Ft. Two Black Hoses W/ One Straight End And One 90 Degree End And 4 Rubber Washers)
"	8212638RP	Inlet Hoses, 6 Ft.
"	285448A	Hose Washers
"	285452A	Hose Filters

