


# Crosley CW18P2WC 03 - EXTERIOR

SECTION: EXTERIOR

MODEL: CW18P2C



Issue Date: 2/91

Crosley [Residential Crosley CW18P2WC Washer Parts](#) Parts Diagram 03 - EXTERIOR

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">35-0581</a>			Bumper, Door
"	<a href="#">35-2103</a>			Clother Door
2	<a href="#">43-0057</a>			Actuator, Door Switch
"	<a href="#">25-7436</a>			Nylite Washer
3	<a href="#">25-7438</a>			Screw
4	<a href="#">33-6957</a>			Hinge Pad
"	25-7086	<a href="#">Y0308025</a>		Washer, Stainless Steel
5	25-7455	<a href="#">99002757</a>		Screw
6	<a href="#">33-6956</a>			Hinge
7	25-7455	<a href="#">99002757</a>		Screw
8	<a href="#">35-2064</a>			Bushing, Insulating
"	<a href="#">35-2063</a>			Bushing, Insulator
9	25-7463	<a href="#">7101P012-60</a>		Screw
10	25-7437	<a href="#">40040701</a>		Screw, Tapping No.6b-20
11	33-9064	<a href="#">12001187</a>		Kit, Lid Switch Assembly
"	35-2814	<a href="#">12001187</a>		Kit, Lid Switch Assembly

12	<a href="#">25-7436</a>		Nylite Washer
"	25-7940	Not Available	SCREW
"	35-2795	<a href="#">12001187</a>	Kit, Lid Switch Assembly
13	<a href="#">25-7878</a>		Clip
14	35-2805	<a href="#">12001187</a>	Kit, Lid Switch Assembly
15	35-2071	Not Available	CABINET TOP
16	25-7733	<a href="#">681414</a>	Screw, 10AB X 1/2
17	35-0680	Not Available	CORD, POWER
18	<a href="#">25-7893</a>		Screw
19	33-7450	<a href="#">35-2846</a>	Hinge, Cabinet Top
20	<a href="#">33-0930</a>		Pad, Top Hinge
21	<a href="#">33-6099</a>		Clamp
25	<a href="#">53-0643</a>		Pin, Locator
26	<a href="#">35-2084</a>		Panel, Front
"	25-7732	<a href="#">681414</a>	Screw, 10AB X 1/2
27	<a href="#">53-0120</a>		Clip, Front Panel
28	<a href="#">33-2653</a>		Bumper, Cabinet
29	35-2106	<a href="#">21001871</a>	Cabinet
30	<a href="#">33-2653</a>		Bumper, Cabinet
31	35-2108	<a href="#">21001871</a>	Cabinet
32	25-7086	<a href="#">Y0308025</a>	Washer, Stainless Steel
NI	33-8057	Not Available	PLASTIC NUT
"	33-8058	Not Available	SPEEDNUT
"	<a href="#">25-6109</a>		Screw
"	<a href="#">34-9701</a>		Guide, Cabinet
"	<a href="#">25-7285</a>		Clip

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>