


Crosley CW20P8HSC 04 - MOTOR & PUMP (ORIG-CW20P8xSC)



Crosley Residential Crosley CW20P8HSC Washer Parts Parts Diagram 04 - MOTOR & PUMP (ORIG-CW20P8xSC)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-0235			Spring, Motor Pivot
2	35-2030		Not Available	MOTOR
"	LA-2002		Not Available	MOTOR KIT
3	33-9945			Slide, Foot
4	25-7418	33001178		Back, Tumbler
5	25-7833	21001977		Screw
6	25-7834			Washer, Motor/Base Screw
7	33-9946			Isolator, Motor
8	33-9944	35-3570		Washer, Motor Pivot
9	25-3083	212951		Screw, No.6-32 X 1/4 Inch
10	33-9947		Not Available	DBL.PIVOT SLIDE
11	35-2021	21001783		Plate And Screw Assembly
12	33-9941	35-3646		Isolator, Motor Plate
13	25-7831			Spacer, Mounting
14	35-2124	W10143344		Pulley
15	25-7117			Set Screw

16	33-9943	35-3571	Slide, Motor Pivot
17	33-9967		Washer, Motor Isolator
18	25-7047		Washer, Flat
19	25-7325	Y707702	Locknut
20	35-2320	21352320	Belt, Drive
21	33-9765		Switch, Motor
22	25-7830		Spacer
23	25-7405	3196164	Screw
24	33-6035	Not Available	PLATE & PULLEY ASSY.
25	33-6032		Gasket
26	35-2058		Base, Pump
27	35-2057	35-6465	Pump Assem
28	35-2056	Not Available	HOUSING, PUMP
"	35-2099	35-6465	Pump Assem
29	33-9436	211704	Hose, Drain
30	35-0707		Seal, Seat And "O" Ring
31	25-7894	W10001180	Screw
32	25-6099	33-6099	Clamp
33	35-2131	Not Available	HOSE, SUMP TO PUMP
34	25-7796	596669	Clamp, Manifold

