


Crosley CW5000W 05 - CONTROL PANEL



Crosley [Residential Crosley CW5000W Washer Parts](#) Parts Diagram 05 - CONTROL PANEL
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|-----------------------|--------|---|
| 1 | 21001550 | | | Panel, Control |
| 2 | 25-3092 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 21001546 | | | Endcap, Panel |
| 3 | 21001547 | | | Endcap, Panel |
| " | 25-3092 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 4 | 25-7851 | | | Speedclip, End Cap To Top |
| 5 | 21001882 | | | Switch, Pressure |
| " | 21001554 | | | Switch, Water Level |
| " | 25-3092 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 6 | 21001520 | | | Skirt, Timer Knob |
| 7 | 21001526 | | | Knob, Timer |
| 8 | 21001553 | | | Frame |
| 9 | 25-3092 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 25-3457 | | | Screw, Sems |

| | | | |
|----|--------------------------|--------------------------|---|
| " | 25-7853 | 25-7933 | Ring, Retaining |
| " | 21001527 | | Shield, Rear |
| 10 | 25-3092 | 90767 | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 21001545 | | Timer |
| 11 | 21001544 | | Knob, Selector |
| 12 | 21001517 | | Shield, Control |
| " | 31001193 | | Pad, Shield |
| " | 53-2504 | 31001193 | Pad, Shield |
| NI | 21001725 | Not Available | MANUAL, USE & CARE (SPAN) |
| " | 21001572 | Not Available | MANUAL, USE & CARE |

Howes
the laundry company®

Howes
the laundry company®

Howes
the laundry company®