


Crosley CW5000W 06 - TOP



Crosley [Residential Crosley CW5000W Washer Parts](#) Parts Diagram 06 - TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-2026			Lid
2	43-0057			Actuator, Door Switch
3	25-7438			Screw
"	25-7436			Nylite Washer
4	35-2045			Pin, Hinge
5	25-7893			Screw
6	35-2044			Hinge, Lid
7	35-0581			Bumper, Door
8	35-2063			Bushing, Insulator
"	35-2064			Bushing, Insulating
9	21001137	12001187		Kit, Lid Switch Assembly
10	21001136	3400872		Screw, 8-18 X 3/8
11	21001148	12001187		Kit, Lid Switch Assembly
12	21001135			Housing, Lid Switch
13	25-7878			Clip
14	21001134			Lever, Lid Switch

15 [21001602](#)
16 [21001597](#)
17 [21001592](#)

Top, Cabinet
Dispenser, Bleach
Cord, Power

