


Crosley CW6500Q 01 - BASE



Crosley [Residential Crosley CW6500Q Washer Parts](#) Parts Diagram 01 - BASE
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	21001110	22004376		Spring, Motor Pivot
2	21001950			MoTor, 2SP 1/2hp 120V/60Hz Hi-Tor
3	21001486			Foot Slide, Isolator
4	21001873	35-6780		Pump-Water
"	21002219	35-6780		Pump-Water
5	21001977			Screw
6	35-2065			Pad, Motor Plate
7	33-9946			Isolator, Motor
8	35-3570			Washer, Motor Pivot
9	21001783			Plate And Screw Assembly
10	35-3646			Isolator, Motor Plate
11	25-7831			Spacer, Mounting
12	21001506	21001950		MoTor, 2SP 1/2hp 120V/60Hz Hi-Tor
"	22004297	21001950		MoTor, 2SP 1/2hp 120V/60Hz Hi-Tor

13	21002015	4312464	Screw
"	22002721		Shield, Motor
14	35-3571		Slide, Motor Pivot
15	33-9967		Washer, Motor Isolator
16	25-7047		Washer, Flat
17	25-7325	Y707702	Locknut
18	12002102	12002773	Spring
"	21002065	12002773	Spring
19	21001166		Hook, Suspension Spring
20	21001754	21001881	Bar, Stabilizer
21	35-2046		Bracket, Stabilizer
22	35-2052		Pin, Stabilizer
23	35-3020	22004469	Leg And Foot Self Stabalizing
24	25-7828	489483	Screw 10-32 X 1/2
25	21001893	12002701	Base Kit
"	21001982	21001281	Damper, Sound Pad
26	25-7845		Speednut, Motor
27	21001915		Hose, Tub To Pump
28	35-3507	25001119	Foot And Pad Assembly
29	21002026		Snubber
"	21001161	21002026	Snubber
30	21352320		Belt, Drive
31	25-7830		Spacer
32	21002254	285655	Clamp, Hose
"	25-6068	285655	Clamp, Hose

the laundry company®

the laundry company®