


# Crosley CW6500Q 03 - CONTROL PANEL



Crosley [Residential Crosley CW6500Q Washer Parts](#) Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">21002019</a>			Panel, Control / Facia
"	<a href="#">21002156</a>			Facia
2	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001769</a>			Endcap, Panel
3	<a href="#">21001768</a>			Endcap, Panel
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	<a href="#">31001443</a>			Switch, Two Pos Rotary
"	<a href="#">31001190</a>			Switch, Two Position Rotary
5	<a href="#">21002067</a>			Shield, Control
"	<a href="#">Y2201474</a>			Switch, Pressure
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001882</a>			Switch, Pressure
6	<a href="#">21001771</a>			Skirt, Timer Knob
7	<a href="#">21001770</a>			Knob, Timer

8	<a href="#">21001226</a>		Switch, Water Temp. 4 Position
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
9	<a href="#">21001767</a>		Frame
10	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001527</a>		Shield, Rear
11	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001561</a>		Timer
12	<a href="#">21001772</a>		Knob, Selector
13	<a href="#">21001603</a>		Shield, Control

