



Crosley [Residential Crosley CW6500W Washer Parts](#) Parts Diagram 04 - SUPPLEMENTAL INFORMATION
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	21002098			Harness, Wire
"	21001946			Harness, Wiring
"	2206667		Not Available	MANUAL, USE & CARE CROSLEY
"	Y2205349		Not Available	MANUAL, USE & CARE
"	35-6891		Not Available	MANUAL, USE & CARE
"	21001980			Lead Assembly
"	21001979			Lead Assembly
"	21002207		Not Available	LABEL, ENERGY GUIDE - CW
"	35-6910			Guide, Energy
"	16008333		Not Available	MANUAL, SRVC WASHER- NO REFUND