


Crosley CW9500W 01 - CABINET & BASE



Crosley [Residential Crosley CW9500W Washer Parts](#) Parts Diagram 01 - CABINET & BASE
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	32671	Y014874		Screw, Idler Arm And Sleeve
2	505187			Locator, Panel
3	500003			Hinge, Top
4	40064801	3390631		Screw, 10-16 X 3/8
5	40076402WP	37001284		Cabinet As Pack
6	40038201	27001200		Screw
7	56080	22001650		Fastener, Spring
8	Y56128			Pad, Bumper
9	40031501			Bracket, Self Leveling
10	40037401			Ring, Friction
11	27001084	27001226		Base Lev
12	40039001	22003428		Leg, Adjustable
13	40038101			Nut, Leg
14	40016001			Foot, Rubber
15	40034101			Screw, No.12bx1/2
16	40045301WP			Panel, Access

17 [40083101](#)
18 [40035401WP](#)
" [22001817](#)

Tape, Foam
Panel, Front
Sheet, Sound Damper

