


Crosley CW9500W 08 - TUB (INNER & OUTER)



Crosley [Residential Crosley CW9500W Washer Parts](#) Parts Diagram 08 - TUB (INNER & OUTER)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	27001195		Not Available	COVER, OUTER TUB W GASKET
2	27001194	21001748		Hose, Pressure Switch
3	27001130			Seal, Tub Cover
4	40111001P			Tub, Plastic Outer
5	27001067			Bottom, Outer Tub
6	27001026	Y37001124		Spring, Tall Tub
7	40064301			Screw, 1/4-15 x 3/4 Hex
8	Y2201244			Spring, Counterweight
9	40000801	719P3		Assembly- Wash
10	40008501			Assembly, Pressure Bulb
11	40037801			Grommet
12	21001905			Dispenser, Fabric
13	40008001			Filter, Lint
14	25-8004	W10309247		Screw
15	22004042			Agitator/Auger Assembly
16	27001052			Balance Ring

