


# Hoover HWA2006W 12 - TRANSMISSION (REV. G-L)



Hoover [Residential Hoover HWA2006W Washer Parts](#) Parts Diagram 12 - TRANSMISSION (REV. G-L)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LA-2175	<a href="#">35-6680</a>		Transmission
"	35-3748	<a href="#">35-6680</a>		Transmission
"	<a href="#">25-7941</a>			"O" Ring, Agrtr Drive Shaft
2	35-2835	<a href="#">21001066</a>		Bearing, Centerpost
3	35-2792	<a href="#">21001401</a>		Center Pos
4	<a href="#">33-6790</a>			Bearing, Agitator
"	35-2983		Not Available	CENTERPOST ASSY.
5	<a href="#">35-2906</a>			Seal, Centerpost Bottom
6	<a href="#">35-2791</a>			Nut, Spin Tube
7	<a href="#">25-7938</a>			"O" Ring, Basket Drive Hub
8	35-2715		Not Available	BASKET DRIVE HUB ASSY
"	35-3647	<a href="#">W10219156</a>		Tub Seal
9	<a href="#">35-2974</a>			Tub Seal/Hub Assembly
10	35-2716	<a href="#">12001561</a>		Bearing And Seal Housing Assembly
11	35-2972	<a href="#">12001561</a>		Bearing And Seal Housing Assembly

"	<a href="#">35-2205</a>		Bearing, Spin
12	25-7949	Not Available	RING, RETAINING (AG. SHAFT)
13	<a href="#">25-7057</a>		Washer, Flat
14	25-7051	<a href="#">25-7057</a>	Washer, Flat
15	25-7895	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
16	<a href="#">35-2981</a>		Cover, Reinforcement
17	25-7895	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
18	<a href="#">35-2621</a>		Plug, Oil Fill
19	25-7926	<a href="#">25-7758</a>	Screw
20	35-2971	Not Available	TRANSMISSION COVER ASSY.
"	35-2620	Not Available	COVER, TRANSMISSION
21	35-2903	Not Available	COUNTERWEIGHT
22	35-1030	Not Available	GASKET, TRANSMISSION HOUSING
23	25-7722	<a href="#">33-4293N</a>	Gasket Kit
24	<a href="#">35-3702</a>		Drive Tube Assembly
"	35-2708	<a href="#">35-3702</a>	Drive Tube Assembly
25	35-3036	<a href="#">35-3804</a>	Linkage Assembly
"	<a href="#">35-3804</a>		Linkage Assembly
26	LA-2176	Not Available	CLUTCH ASSY.
27	<a href="#">25-7847</a>		Ring, Retaining
28	25-7415	Not Available	WASHER, FLAT
"	25-7416	Not Available	WASHER, FLAT
29	33-6114	<a href="#">33-6463</a>	Spring
30	<a href="#">35-2001</a>		Pinion, Drive
31	33-3195	Not Available	SPRING
32	<a href="#">35-2692</a>		Drive Shaft And Hub Assembly
33	25-7274	Not Available	WASHER, STEEL
34	35-2817	<a href="#">35-3825</a>	Washer, Nylon
35	<a href="#">35-2070</a>		Washer, Steel W/Tabs
36	<a href="#">25-7933</a>		Ring, Retaining
37	<a href="#">35-2527</a>		Gear, Cluster
38	35-2631	Not Available	GEAR, CRANK
39	35-2812	Not Available	HOUSING, TRANSMISSION
40	35-2010	<a href="#">207843</a>	Lip Seal Repair Kit
41	35-2730	<a href="#">12001562</a>	Bearing Assembly
"	35-2973	<a href="#">35-6680</a>	Transmission
42	35-2732	<a href="#">21001518</a>	Support, Tub
"	35-3724	<a href="#">21001518</a>	Support, Tub
43	35-2798	Not Available	TUB BRACE
44	25-7930	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
45	35-2015	Not Available	SUSPENSION HOUSING
"	35-3698	Not Available	HOUSING, SUSPENSION
46	<a href="#">35-2017</a>		Retainer, Brake Spring
47	35-2112	<a href="#">21001910</a>	Spring, Brake
48	25-7930	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
"	35-2025	Not Available	PLATE, REINFORCEMENT
49	25-7895	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
50	35-2948	<a href="#">35-6714</a>	Brake Roto
51	35-2357	<a href="#">21002026</a>	Snubber
52	35-2018	<a href="#">35-6918</a>	Stator, Brake

53	25-7900	<a href="#">21001065</a>	Screw, No.10-24 x .50 Hxnibhd
54	W10124350		Not Available
55	W10124350		Not Available
56	W10124350		Not Available
57	W10124350		Not Available
58	W10124350		Not Available
59	35-2683	<a href="#">12002213</a>	Thrust Bearing Kit
60	35-2439	<a href="#">12002213</a>	Thrust Bearing Kit
61	<a href="#">35-2132</a>		Washer, 1.25ODX.530IDX.032
"	<a href="#">35-2082</a>		Washer, 1.25ODX.530IDX.062
62	<a href="#">25-7854</a>		Ring, Retaining
63	<a href="#">35-2007</a>		Cap, Dust
64	12500036	<a href="#">12002213</a>	Thrust Bearing Kit

