


Hoover SHWA2507V 02 - CONTROL PANEL



Hoover [Residential Hoover SHWA2507V Washer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35-3830		Not Available	CONTROL PANEL
"	25-3457			Screw, Sems
2	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-7649	910187		Screw
3	25-7702			Speedclip, End Cap To Control Panel
4	53-0277		Not Available	TRIM, END CAP (RT)
"	53-0278		Not Available	TRIM, END CAP (LT)
5	35-2669		Not Available	CAP, END (LT)(WHT)
"	35-2668	21001453		Cap- End
6	35-3190		Not Available	SHIELD, CONTROL
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	35-3743			Timer
8	25-0205	216412		Screw, Bracket To Timer
9	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

"	35-3283	21001554	Switch, Water Level
10	35-3192	Not Available	SWITCH 5 PUSHBUTTON
11	35-3193		Switch 4 Pushbutton
12	33-6621	Not Available	BRACKET, SWITCH
13	35-3515	Not Available	PAD, SWITCH
14	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-7712	Not Available	SCREW
15	35-3191		Pushbutton
16	35-3203		Switch, Paddle Momentary
17	35-3204		Switch, Paddle 2 Pos.
18	35-2672	21001237	Knob, Timer
19	35-2950	21001502	Skirt Ri
20	35-2673	21001239	Knob, Selector
21	35-2688	21001460	Shield, Rear
"	25-3457		Screw, Sems
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
22	25-7852		Speedclip, Rr Shld To End Cap
23	25-7851		Speedclip, End Cap To Top
24	25-7760		Screw
NI	35-3740	Not Available	MANUAL, USE & CARE
"	33-8304-2	Not Available	MANUAL, USE & CARE

