


# Inglis IGD4400VQ2 01 - TOP AND CONSOLE PARTS



Inglis [Residential Inglis IGD4400VQ2 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10115228		Not Available	INSTRUCTIONS, INSTALLATION
"	W10287575		Not Available	GUIDE, USE & CARE
"	<a href="#">W10185979</a>			Wiring Diagram Cycle Feature
2	8533951	<a href="#">3400859</a>		Screw, Grounding
3	<a href="#">8538959</a>			Knob, Push-To-Start
4	8274434	<a href="#">279960</a>		Endcap
5	<a href="#">8558463</a>			HAndle And Lint Screen Assembly
6	<a href="#">688805</a>			Clip, Spring Knob
7	<a href="#">357213</a>			Nut, Push-In
8	688983	<a href="#">487240</a>		Screw, For Mtg. Service Capacitor
9	<a href="#">8536939</a>			Clip, Knob
10	<a href="#">693995</a>			Screw, Hex Head
11	8557930	<a href="#">8563985</a>		Top
12	<a href="#">8274261</a>			Do-It-Yourself Repair Manuals

13	<a href="#">W10185971</a>		Timer Assembly, 60 Hz
14	3348629	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
15	<a href="#">W10186074</a>		Harness, Wiring
16	<a href="#">3977456</a>		Switch, Push-To-Start
17	<a href="#">8538953</a>		Timer Knob Assembly
18	<a href="#">8271418</a>		Bracket, Control
19	<a href="#">W10207807</a>		Panel, Control
20	<a href="#">388326</a>		Screw, 8-18 X 1.25
21	8274437	<a href="#">279960</a>	Endcap

