


Inglis IV4800X0 03 - AGITATOR, BASKET AND TUB PARTS



Inglis [Residential Inglis IV4800X0 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8533251			Dispenser, Fabric Softener
2	358237			Screw And Washer
3	3949550			Washer
4	W10297437	353244		Hose, Pressure Switch
5	2219077			Clip, Pressure Switch Hose
6	3361598	285727		Agitator
7	3363662	285748		Cam-Agitator
8	3366877	80040		Dog-Agitator
9	3363661			Bearing, Driven Cam
10	3360824			Auger, Agitator
11	3350389	285587		Washer
12	389386			Agitator
13	8528150	W10445870		Ring-Tub
14	3976308			Gasket, Tub Ring
15	3354845			Clip, Agitator
16	8543666			Washer, Agitator

17	21366		Nut, Spanner
18	8526016	W10389328	Clothes Container, Assembly
19	387240		Ring, Balance
20	63849		Strain Relief, Power Cord
21	389140		Tub Block, Basket Drive
22	383727		Gasket, Centerpodt

