

# Inglis YIED4700YQ0 01 - TOP AND CONSOLE PARTS




## TOP AND CONSOLE PARTS

For Model: YIED4700YQ0  
(White)

29" ELECTRIC DRYER

by Whirlpool Corporation



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1-12 Litho in U.S.A (JLP)(bay)

1

Part No. W10481565 REV. A

[Inglis Residential Inglis YIED4700YQ0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

| Item | Original Part Number      | Replaced By           | Status        | Part Description                        |
|------|---------------------------|-----------------------|---------------|---|
| 1    | W10096991                 |                       | Not Available | GUIDE, USE & CARE                       |
| "    | W10115228                 |                       | Not Available | INSTRUCTIONS, INSTALLATION              |
| "    | W10185986                 |                       | Not Available | WIRING DIAGRAM                          |
| 2    | <a href="#">W10446920</a> |                       |               | Switch, Push To Start                   |
| 3    | <a href="#">693995</a>    |                       |               | Screw, Hex Head                         |
| 4    | <a href="#">W10112603</a> |                       |               | Seal, Harness                           |
| 5    | <a href="#">W10416486</a> |                       |               | Panel, Rear Console                     |
| 6    | <a href="#">W10112578</a> |                       |               | Harness, Bracket                        |
| 7    | <a href="#">694419</a>    |                       |               | Mini-Buzzer                             |
| 8    | <a href="#">8312709</a>   |                       |               | Clip-Console                            |
| 9    | <a href="#">W10420747</a> |                       |               | Switch, Temperature                     |
| 10   | <a href="#">8558463</a>   |                       |               | HANdle And Lint Screen Assembly         |
| 11   | <a href="#">8536939</a>   |                       |               | Clip, Knob                              |
| 12   | 3348629                   | <a href="#">90767</a> |               | Screw, 8A X 3/8 HeX Washer Head Tapping |

|    |                           |                         |                                   |
|----|---------------------------|-------------------------|-----------------------------------|
| 13 | 688983                    | <a href="#">487240</a>  | Screw, For Mtg. Service Capacitor |
| 14 | W10450290                 | Not Available           | HARNES, WIRING                    |
| 15 | 8559800                   | <a href="#">8563663</a> | Top                               |
| 16 | <a href="#">W10453947</a> |                         | Knob, Control                     |
| 17 | <a href="#">W10436303</a> |                         | Timer, 60 Hz                      |
| 18 | W10115482                 | Not Available           | PANEL, CONSOLE                    |
| 19 | <a href="#">W10453946</a> |                         | Timer Knob Assembly               |
| 20 | <a href="#">357213</a>    |                         | Nut, Push-In                      |

