


# Jenn-Air JW2000W 05 - TRANSMISSION (SERIES 10)



Jenn-Air Residential Jenn-Air JW2000W Washer Parts Parts Diagram 05 - TRANSMISSION (SERIES 10)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">25-7941</a>			"O" Ring, Agr Drive Shaft
2	<a href="#">21001066</a>			Bearing, Centerpost
3	35-2983		Not Available	CENTERPOST ASSY.
"	35-2792	<a href="#">21001401</a>		Center Pos
4	<a href="#">33-6790</a>			Bearing, Agitator
5	<a href="#">35-2906</a>			Seal, Centerpost Bottom
6	<a href="#">35-2791</a>			Nut, Spin Tube
7	<a href="#">25-7938</a>			"O" Ring, Basket Drive Hub
8	35-3647	<a href="#">W10219156</a>		Tub Seal
9	<a href="#">35-2974</a>			Tub Seal/Hub Assembly
10	35-2716	<a href="#">12001561</a>		Bearing And Seal Housing Assembly
11	<a href="#">35-2205</a>			Bearing, Spin
12	25-7949		Not Available	RING, RETAINING (AG. SHAFT)
13	<a href="#">25-7057</a>			Washer, Flat
14	<a href="#">25-7057</a>			Washer, Flat

15	25-7895	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
16	<a href="#">35-2981</a>		Cover, Reinforcement
17	25-7895	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
18	<a href="#">35-2621</a>		Plug, Oil Fill
19	<a href="#">25-7758</a>		Screw
20	35-2620	Not Available	COVER, TRANSMISSION
21	<a href="#">35-3706</a>		Counterweight
22	35-0542	Not Available	GASKET, TRANSMISSION HOUSING
23	<a href="#">33-4293N</a>		Gasket Kit
24	<a href="#">35-3702</a>		Drive Tube Assembly
25	<a href="#">35-3804</a>		Linkage Assembly
26	35-2025	Not Available	PLATE, REINFORCEMENT
27	<a href="#">25-7847</a>		Ring, Retaining
28	25-7415	Not Available	WASHER, FLAT
29	35-3384	Not Available	STOP, ANTIBACKUP CAM
30	<a href="#">35-2001</a>		Pinion, Drive
31	35-3608	Not Available	SPRING, CLUTCH
32	<a href="#">35-2692</a>		Drive Shaft And Hub Assembly
33	25-7274	Not Available	WASHER, STEEL
34	<a href="#">35-3825</a>		Washer, Nylon
35	<a href="#">35-2070</a>		Washer, Steel W/Tabs
36	<a href="#">25-7933</a>		Ring, Retaining
37	<a href="#">35-2527</a>		Gear, Cluster
38	21001067	Not Available	GEAR, CRANK
39	35-2812	Not Available	HOUSING, TRANSMISSION
40	35-2010	<a href="#">207843</a>	Lip Seal Repair Kit
41	35-2730	<a href="#">12001562</a>	Bearing Assembly
42	21001162	<a href="#">21001518</a>	Support, Tub
43	21001164	Not Available	BRACE, TUB
44	25-7895	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
45	<a href="#">21001163</a>		Housing, Suspension
46	<a href="#">35-2017</a>		Retainer, Brake Spring
47	35-2112	<a href="#">21001910</a>	Spring, Brake
48	25-7895	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
49	25-7895	<a href="#">21001858</a>	Screw 5/16-18 x 1/2
50	35-2948	<a href="#">35-6714</a>	Brake Roto
51	21001161	<a href="#">21002026</a>	Snubber
52	35-2018	<a href="#">35-6918</a>	Stator, Brake
53	<a href="#">21001065</a>		Screw, No.10-24 x .50 Hxnibhd
54	35-3829	<a href="#">12002213</a>	Thrust Bearing Kit
55	LA-2007	<a href="#">12002213</a>	Thrust Bearing Kit
56	LA-2176	Not Available	CLUTCH ASSY.
57	35-2973	<a href="#">35-6680</a>	Transmission
58	<a href="#">35-2007</a>		Cap, Dust
59	12500036	<a href="#">12002213</a>	Thrust Bearing Kit
60	35-2972	<a href="#">12001561</a>	Bearing And Seal Housing Assembly
61	21001168	<a href="#">35-6680</a>	Transmission