


# Jenn-Air LSE2700W-8 08 - CONTROL PANEL



Jenn-Air Residential Jenn-Air LSE2700W-8 Stacked Washer and Dryer Parts Parts Diagram 08 - CONTROL PANEL  
Click on the part number to view part

| Item | Original Part Number    | Replaced By               | Status        | Part Description                        |
|------|-------------------------|---------------------------|---------------|---|
| 1    | <a href="#">314286</a>  |                           |               | Seal For Front Panel                    |
| 2    | <a href="#">212277</a>  |                           |               | Screw, No.8 X 1/2 Inch                  |
| 3    | Y305753                 | <a href="#">W10169313</a> |               | Switch-Dor                              |
| 4    | <a href="#">Y314261</a> |                           |               | Switch And Relay Bracket                |
| 5    | <a href="#">Y310376</a> |                           |               | Clip, Door Switch Harness               |
| 6    | Y313927                 |                           |               | INSTRUCTION LABEL                       |
| 7    | <a href="#">306436</a>  |                           |               | Door Latch Kit--W                       |
| 8    | <a href="#">308017</a>  |                           |               | Switch, Dryer Temperature               |
| 9    | 213966                  | <a href="#">3400014</a>   |               | Screw                                   |
| 10   | <a href="#">207782</a>  |                           |               | Switch, Water Temperature               |
| 11   | <a href="#">207800</a>  |                           |               | Switch, Water Level                     |
| 12   | 211294                  | <a href="#">90767</a>     |               | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 13   | 208071                  |                           | Not Available | DIAL, TIMER                             |
| 14   | 315267                  |                           | Not Available | END CAP,CONTROL PANEL (BLK)             |
| 15   | 211000                  |                           |               | SCREW, BRAKE DRUM (HEX                  |

|    |                         |                           |                              |
|----|-------------------------|---------------------------|------------------------------|
| 15 | <a href="#">211000</a>  |                           | HEAD)                        |
| 16 | <a href="#">211065</a>  |                           | Spring, Index Wheel          |
| 17 | <a href="#">Y216047</a> |                           | Knob, Control                |
| 18 | 216048                  | Not Available             | CAP, KNOB                    |
| 19 | <a href="#">211605</a>  |                           | Bezel, Timer Dial            |
| 20 | <a href="#">312273</a>  |                           | Nut, Control Knob            |
| 21 | <a href="#">315408</a>  |                           | Knob, Control                |
| 22 | <a href="#">308411</a>  |                           | Knob, Rotary                 |
| 23 | 380412                  | Not Available             | TIMER DIAL-DRYER             |
| 24 | <a href="#">215952</a>  |                           | Screw                        |
| 25 | 308409                  | <a href="#">Y308025</a>   | Switch, Push To Start        |
| 26 | 308418                  | Not Available             | FACIA CONTROL PANEL          |
| 27 | <a href="#">215952</a>  |                           | Screw                        |
| 28 | <a href="#">315237</a>  |                           | Bracket For Switch And Timer |
| 29 | <a href="#">Y308252</a> |                           | Timer                        |
| 30 | <a href="#">314482</a>  |                           | Fastener, Spring             |
| 31 | 314748                  | <a href="#">488660</a>    | Nut, Speed                   |
| 32 | 314486                  | Not Available             | LABEL                        |
| 33 | <a href="#">207783</a>  |                           | Timer                        |
| 34 | 215960                  | Not Available             | STRAIN RELIEF                |
| 35 | <a href="#">208213</a>  |                           | Wire Harness                 |
| 36 | 215953                  | Not Available             | SCREW                        |
| 40 | 211168                  | <a href="#">W10139210</a> | Screw, 8-18 X 5/16           |
| 42 | Y308018                 | Not Available             | WIRE HARNESS (DRYER)         |
| 44 | <a href="#">315286</a>  |                           | Bumper Large                 |
| 45 | <a href="#">315287</a>  |                           | Bumper Small                 |

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>