


Jenn-Air LSG2700W 08 - CONTROL PANEL



Jenn-Air [Residential Jenn-Air LSG2700W Stacked Washer and Dryer Parts](#) Parts Diagram 08 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314286			Seal For Front Panel
2	212277			Screw, No.8 X 1/2 Inch
3	Y305753	W10169313		Switch-Dor
4	Y314261			Switch And Relay Bracket
5	Y310376			Clip, Door Switch Harness
6	Y313927			INSTRUCTION LABEL
7	306436			Door Latch Kit--W
8	308017			Switch, Dryer Temperature
9	213966	3400014		Screw
10	207782			Switch, Water Temperature
11	207800			Switch, Water Level
12	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
13	208071		Not Available	DIAL, TIMER
14	315267		Not Available	END CAP,CONTROL PANEL (BLK)
15	211000			SCREW, BRAKE DRUM (HEX

15	211000		HEAD)
16	211065		Spring, Index Wheel
17	Y216047		Knob, Control
18	216048	Not Available	CAP, KNOB
19	211605		Bezel, Timer Dial
20	312273		Nut, Control Knob
21	315408		Knob, Control
22	308411		Knob, Rotary
23	380412	Not Available	TIMER DIAL-DRYER
24	215952		Screw
25	308409	Y308025	Switch, Push To Start
26	308418	Not Available	FACIA CONTROL PANEL
27	215952		Screw
28	315237		Bracket For Switch And Timer
29	Y308252		Timer
30	314482		Fastener, Spring
31	314748	488660	Nut, Speed
32	314486	Not Available	LABEL
33	207783		Timer
34	215960	Not Available	STRAIN RELIEF
35	208213		Wire Harness
36	215953	Not Available	SCREW
40	211168	W10139210	Screw, 8-18 X 5/16
42	308019	Not Available	WIRE HARNESS
44	315286		Bumper Large
45	315287		Bumper Small

the laundry company[®]

the laundry company[®]