


Jenn-Air LSG2704W 05 - CONTROL PANEL



Jenn-Air Residential Jenn-Air LSG2704W Stacked Washer and Dryer Parts Parts Diagram 05 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314286			Seal For Front Panel
2	212277			Screw, No.8 X 1/2 Inch
3	33001509	W10169313		Switch-Dor
"	Y305753	W10169313		Switch-Dor
4	33001191			Panel, Front
5	Y310376			Clip, Door Switch Harness
6	315287			Bumper Small
7	Y304578	LA-1003		Door Catch Kit
8	308017			Switch, Dryer Temperature
9	216042	22001627		Screw
10	207782			Switch, Water Temperature
11	22001188			Switch, Rotary
12	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
13	22001033			Knob, Timer
14	33001578		Not Available	CAP, END (OFF-WHT)
				END CAP CONTROL PANEL

"	315267		Not Available	END CAP, CONTROL PANEL (BLK)
15	211000			SCREW, BRAKE DRUM (HEX HEAD)
16	211065			Spring, Index Wheel
17	Y216047			Knob, Control
18	216048		Not Available	CAP, KNOB
19	211605			Bezel, Timer Dial
20	312273			Nut, Control Knob
21	315408			Knob, Control
22	308411			Knob, Rotary
23	33001011		Not Available	DIAL, TIMER
24	315317	488234		Screw 8-32 X 1/4
25	308409	Y308025		Switch, Push To Start
26	33001007		Not Available	PANEL, CONTROL (WHT)
27	215952			Screw
28	315237			Bracket For Switch And Timer
29	33001034			Timer, Dryer
30	314482			Fastener, Spring
31	33001292	488660		Nut, Speed
32	315286			Bumper Large
33	22001180			Timer
34	22001429			Wire Harness, Main
"	208774		Not Available	WIRE HARNESS (UPR)
35	22001432			Wire Harness
"	22001585			Harness, Wire
"	208776		Not Available	WIRE HARNESS (LOWER)
36	33001043			Wire Harness, Dryer
"	33001369			Wire Harness, Dryer
"	33001554			Harness, Wire

