


# Magic Chef CAV2000AWQ 05 - CONTROL PANEL



Magic Chef [Residential Magic Chef CAV2000AWQ Washer Parts](#) Parts Diagram 05 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">21001808</a>			Panel, Control
2	<a href="#">21001769</a>			Endcap, Panel
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	<a href="#">21001768</a>			Endcap, Panel
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001139</a>			Switch, Water Temp. 3 Position
5	<a href="#">21001554</a>			Switch, Water Level
"	<a href="#">21001882</a>			Switch, Pressure
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
6	<a href="#">21001771</a>			Skirt, Timer Knob
7	<a href="#">21001770</a>			Knob, Timer
8	<a href="#">21001517</a>			Shield, Control

9	<a href="#">21001767</a>			Frame
10	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001527</a>			Shield, Rear
11	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001522</a>			Timer
12	<a href="#">21001772</a>			Knob, Selector
NI	21001725		Not Available	MANUAL, USE & CARE (SPAN)
"	21001573		Not Available	MANUAL, USE & CARE
"	<a href="#">12002417</a>			Wire Kit
"	<a href="#">21001785</a>			Harness, Wire
"	<a href="#">21001933</a>			Harness, Wiring

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>